
INS14024 - 7/16

MOEN®

喷头



文中图片仅供参考 (款式因型号而异)

如需安装支持,配件丢失或替换等,请联系本公司。 对于中国大陆以外的市场,请咨询当地经销商 (中国大陆) 400-630-8866 (中国大陆) www.moen.cn (中国大陆)以外) www.moen.com.hk

©2024 Fortune Brands Innovations Incorporated

注意事项:

本公司厨卫产品以精湛的技术制造而成,保证品 质优良,美观耐用。


清洁产品时须小心,避免对产品表面造成损害。 请用清水或中性的清洁剂清洁产品表面,然后以 柔软的毛巾抹干:

切勿使用含化学成分或腐蚀性的清洁剂、粗糙的 布料抹擦。

建议定期清洗产品,以保证其外观光洁明亮。 使用酸性清洁剂清洗附近物品时,有可能损害产品表面,请加倍小心。







- 1.在安装位置打1组深40mm,Ø5的孔,中心距为24mm。
- 2.将2个膨胀管打进孔中,端面与墙面齐平。
- 3.用自攻螺丝穿过支座安装孔,将产品锁紧到安装位置。
- 4.用手扳动支座,检查支座是否安装牢固,无明显晃动。





产品售后保修条款

本产品是在高质量标准及生产工艺下制造的,本公司承诺为 消费者购买的产品提供有期限免费保修及终身维修服务。 浴室配件免费保修期为1年,均自消费者购买日(以本产品 分销商开具的发票或收据上载明日期为准)起计。

免费保修范围为产品及产品配件由于材质及工艺原因而造成的故障或损坏。免费保修期内,我们将无偿为您提供修理服务及更换发生故障的产品或产品配件。本公司的售后服务责任仅限于对故障产品的修理,而不延及您因产品故障而发生的其他损失,法律另有规定的除外。

您需了解:产品外观碰伤、刻划痕迹,以及滥用及不正当 保养所导致的故障或损坏,均不属于免费保修范围。即使 在免费保修期内,属下列(1)-(5)情况之一的,需酌 情收取修理费用.

- 1. 不能出示相符的保修卡和有效购买凭证情况的;
- 2. 未按使用说明书告知的使用方法和注意事项造成的故障:
- 3. 自行拆卸、维修、改装所造成的故障和损坏;
- 4. 由于不可抗力等外部原因引起的故障和损坏;
- 5. 由于运输、搬卸、挤压等造成的损坏。

对于保修期外或不在保修范围内的产品,如需维修,本公司将酌情收取上门费、人工费及材料费。

本保修条款仅对原始消费者和酒店行业的购买者有效,并不适用于本产品在工业、商业、贸易和非酒店行业的使用。

如对本保修条款内容有任何疑问,请拨打4006308866 咨询热线,或向当地分销商咨询。对于中国大陆以外的市场,此产品的保修及保障服务详情请咨询当地经销商。 本公司对本产品保修拥有最终解释权。



INS14024 - 7/16

MOEN®摩恩

Spray



The pictures in the text are for referene only (The style varies by model)

For installation support, missing or replacing parts, etc., please contact the company. For consumers in markets outside the Chinese mainland, please consult the local dealer.

(Chinese Mainland) 400-630-8866

(Chinese Mainland) www.moen.cn

(Outside Chinese Mainland) www.moen.com.hk

©2024 Fortune Brands Innovations Incorporated

CAUTIONS:

soft towel;


The company's kitchen products are made with superb technology to ensure high quality, beautiful and durable.


Be careful when cleaning the product to avoid damage to the surface of the product. Please clean the surface of the product with water or neutral detergent, and then dry it with a

Do not use chemical or corrosive cleaners or rough cloths.


It is recommended to clean the product regularly to ensure its appearance is bright and clean. When using acidic cleaners to clean nearby items, it may damage the surface of the product. Please be extra careful.








- 1.Drill 1 set of 40mm deep and \emptyset 5 holes at the mounting position with 24mm center distance.
- 2.Insert two screw chassis into the holes.
- 3. Use screws through the mounting holes of the bracket to lock the bracket into the mounting position.
- 4.Use your hand to check that the bracket is firmly installed without any obvious vibration.





PRODUCT LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for the products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by the company distributors) and shall cover a period of the following: the warranty period for Bath accessory is 1 year.

This warranty is your coverage against material and workmanship malfunction or defects in the products or components. During the warranty period, we offer free maintenance and changing of malfunctioned products or product components. the company's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for otherwise stipulated by law. Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty. Although the warranty period remains valid, in case of the following conditions [1] - [5], the maintenance cost (material cost and labor cost) shall still be charged as the case may be:

- Corresponding warranty card and valid invoice cannot be presented;
- 2. Faults were caused by the incompliance with the instructions and precautions provided in the user's manual;
- 3. Damages and faults were caused by self-actuated dismantling, repair and refit;
- 4. Faults and damages were caused by external factors such as force majeure;

5. Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities.

In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as thecase may be.

Please call 400-630-8866 or contact local dealer for any question. For markets exclude Chinese mainland, the terms and conditions of warranty shall differ between product categories and countries. Please refer to warranty stated by local distribution.

The company Incorporated shall have the final interpretation of the product warranties.

