MOEN®學恩 反冲洗手持花洒



HH2001 系列

文中图片仅供参考 (款式因型号而异)

如需安装支持,配件丢失或替换等,请联系本公司。 对于中国大陆以外的市场,请咨询当地经销商 (中国大陆) 400-630-8866 (中国大陆) www.moen.cn

(中国大陆以外) www.moen.com.hk

©2025 Fortune Brands Innovations Incorporated

注意事项

- 本产品已经出厂检测及调试,请勿自行拆卸。
- 安装前请先彻底冲洗供水管以清除管道中的杂 质。花洒的推荐工作压力: 0.2~0.5MPa (2~5Bar); 花洒的最高工作压力: 0.5MPa (5Bar)。水压超过0.5MPa (5Bar) 需安装减压
- 花洒最高工作温度及环境温度: 60℃ 请特别注意花洒及花洒软管须远离加热器, 否则 可能损坏花洒及其密封件, 甚至对使用者造成伤
- 出水面板在运输过程中可能出现角度错位, 使用 前需对面板进行位置校正, 翻转排渣, 切换出水 模式时需将出水面板进行复位校正,避免出现水
- 暂停按键可用于反冲洗排渣、出水模式切换、面 板更换:长期止水可能导致出水管憋压出现爆裂 的风险。

产品功能特点

- 绵密水
- 按摩水
- 增压水

安装与使用: 单位: 毫米 75 217.

安装说明

- 1. 将垫片(1)(用户自备)放入软管(3)(用户自备)
- 2.将手持花洒②旋紧在软管上: 软管的另一端连接

花洒使用说明

1.按住按键暂停出水, 180° 翻转翻板切换出水模

2.关闭水源, 90° 翻转翻板, 可从安装槽内取出更 换增压面板,以实现不同的水花功能。

3. 节水单向阀装于进水孔内, 防止水管负压时水倒 吸(安装后水压会下降,低水压家庭建议不装)。



花洒外形因不同型号而不同, 上图仅供参考

清洗说明

如何清除出水口水垢和过滤组件杂质:

出水孔在使用一段时间后可能会堆积杂质或结垢导 致水流变形、流量减小,可按以下方式清洗:

- 1.翻转出水面板,反向冲洗可排泥沙,铁锈等杂
- 2. 遇硬化沉积水垢,可用柠檬酸浸泡后,采用牙刷 刷洗清洁出水面板。

如何清洁花洒:

- 为保持花洒洁净,请定期清洁。
- 先用清水或中性的液体清洁剂清洗,再用干净的 软布彻底擦干整个表面。
- 切勿使用任何具有酸性和研磨作用的清洁剂。
- 禁止使用钢丝球、钢丝刷等硬质物品清洗,以免 划伤产品外表面。

产品售后保修条款

本产品是在高质量标准及生产工艺下制造的、本公司承诺为 消费者购买的产品提供有期限免费保修及终身维修服务。 浴室配件免费保修期为1年,均自消费者购买日(以本产品 分销商开具的发票或收据上载明日期为准)起计。

免费保修范围为产品及产品配件由于材质及工艺原因而造 成的故障或损坏。免费保修期内,我们将无偿为您提供修 理服务及更换发生故障的产品或产品配件。本公司的售后 服务责任仅限于对故障产品的修理,而不延及您因产品故 障而发生的其他损失, 法律另有规定的除外。

您需了解:产品外观碰伤、刻划痕迹,以及滥用及不正当 保养所导致的故障或损坏, 均不属于免费保修范围。即使 在免费保修期内,属下列(1)-(5)情况之一的,需酌 情收取修理费用:

- 1. 不能出示相符的保修卡和有效购买凭证情况的:
- 2. 未按使用说明书告知的使用方法和注意事项造成的故障:
- 3. 自行拆卸、维修、改装所造成的故障和损坏;
- 4. 由于不可抗力等外部原因引起的故障和损坏;
- 5. 由于运输、搬卸、挤压等造成的损坏。

对于保修期外或不在保修范围内的产品,如需维修,本公 司将酌情收取上门费、人工费及材料费。

本保修条款仅对原始消费者和酒店行业的购买者有效,并 不适用于本产品在工业、商业、贸易和非酒店行业的使用。

如对本保修条款内容有任何疑问,请拨打400 630 8866 咨询热线,或向当地分销商咨询。对于中国大陆以外的市 场,此产品的保修及保障服务详情请咨询当地经销商。 本公司对本产品保修拥有最终解释权。





MOEN®摩恩

Anti-clogging Handheld Shower



HH2001 Series

The pictures in the text are for referene only (The style varies by model)

For installation support, missing or replacing parts, etc., please contact the company. For consumers in markets outside the Chinese mainland, please consult the local dealer.

[Chinese Mainland] 400-630-8866
[Chinese Mainland] www.moen.cn

(Chinese Mainland) www.moen.cn (Outside Chinese Mainland) www.moen.com.hk

©2025 Fortune Brands Innovations Incorporated

CAUTIONS:

- The product has passed the functionality test before ex-factory, please do not dismantle by yourself at will.
- Flush the water supply pipes thoroughly to remove debris.
- Recommended working pressure: 0.2~0.5Mpa (2~5Bar). The highest working pressure is 0.5Mpa (5Bar). If it exceeds 0.5Mpa (5Bar), a pressure reducer is needed.
- The highest water and environment temperature is 60°C. Please keep showerhead away from heater, or it may be damaged and cause injury to the user.
- The shower panel may become misaligned during transportation. Before use, realign the panel to its correct position. Make sure the panel is in right position to prevent water leakage when using it.
- The pause button can be temperately stop to flip and change the panel. Prolonged water stagnation may result in pressure buildup, posing a risk hose rupture.

Function Features

- Dense spray
- Massage Spray
- Pressurized Spray


Unit:mm 75 621/2

Installation:

- 1. Put the sealer 1(Prepared by customer) into the connect part of the hose 3(Prepared by customer)
- 2. Screw the shower head 2 onto the hose; The other end of the hose is connected to the water supply

Instruction:

- 1. Press the button to pause the water flow, and flip the panel 180° to switch the water spray
- 2. Turn off the water, flip the panel 90°, and remove the original panel to pressurized panel to achieve different water spray functions.
- 3. The check valve is installed in the water inlet hole to prevent water from being sucked back when the water pipe is under negative pressure (the water pressure will drop after installation, and it is recommended not to install it in low water pressure households).



The appearance of the Handheld Shower varies according to the different models. The figure above is for reference only.

Cleaning Instruction

How to clean the watering outlet panel:

After a period of use, the water outlet may accumulate impurities or scales, causing water flow deformation and reduced flow. It can be cleaned in the following ways:

- 1. Reverse the water outlet panel a flush out the impurities such as mud, rust, etc from the opposite side.
- 2.In case of lime scale, soak it in citric acid and then use a toothbrush to clean the water outlet panel.

How to clean the shower:

- 1. To keep the shower clean, wash it regularly
- 2. Rinse with clean water or a neutral liquid cleaner, then thoroughly dry the entire surface with a clean, soft cloth
- 3. Do not use any detergent that is acidic and abrasive
- 4. Do not use steel ball, steel brush and other hard items to clean, so as not to scratch the outer surface of the product

PRODUCT LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for the products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by the company distributors) and shall cover a period of the following: the warranty period for Bath accessory is 1 year.

This warranty is your coverage against material and workmanship malfunction or defects in the products or components. During the warranty period, we offer free maintenance and changing of malfunctioned products or product components. the company's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for otherwise stipulated by law. Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty. Although the warranty period remains valid, in case of the following conditions [1] - [5], the maintenance cost (material cost and labor cost) shall still be charged as the case may be:

- 1. Corresponding warranty card and valid invoice cannot be presented;
- 2. Faults were caused by the incompliance with the instructions and precautions provided in the user's manual;
- 3. Damages and faults were caused by self-actuated dismantling, repair and refit
- Faults and damages were caused by external factors such as force majeure;

5. Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities.

In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as thecase may be.

Please call 400-630-8866 or contact local dealer for any question. For markets exclude Chinese mainland, the terms and conditions of warranty shall differ between product categories and countries. Please refer to warranty stated by local distribution.

The company Incorporated shall have the final interpretation of the product warranties.





Noen service applet

03/05/025 INS15153 50(00/06/079)