
MOEN®

One-handle in Wall Lavatory Rough-in/Lavatory Trim Kit

INSTALLATION INSTRUCTIONS



PLEASE CONTACT MOEN FIRST
For Installation Help, Missing or Replacement Parts, please consult your local dealer.

www.moen.com.hk

HELPFUL TOOLS

For safety and ease of replacement, Moen recommends the use of these helpful tools.




Image is for reference only
(Style varies by model)

Record Purchased Model Number:
(Save instruction sheet for future reference)


07/09/2015 INS2329B 3000056605
Replaced 0

MOEN®


Precautions Before Installation


Caution: Always turn water OFF before removing existing or disassembling the faucet. Open faucet handles to relieve water pressure and insure that complete water shut-off has been accomplished.

Flush hot and cold water supply lines to remove any debris that has accumulated in the supply lines that could damage the faucet.



Installation Dimensions







From Top Side	From Left Side

07/16/2015 13:52:29.0 5000056615
Released 01

1




2




Finished wall surface should be between A Line and B Line.
Adjustment range is 25mm.

3




4

Wring out these two covers by hand




5




Thread the handle dome to the end.

6




Push the escutcheon against the wall.

7



Apply silicon oil on o-rings and connecter.

8



07/06/2015 13:52:29 5000056615
Released 01

MOEN®

MOEN LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for Moen products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by Moen distributors) and shall cover a period of the following: the warranty period for cartridge is 5 years, the warranty period for solenoid valve sensor is 2 years, the warranty period of other accessories such as shower bar, hose, shower, drain assembly, handle, cover, lift rod, aerator etc. is 1 year.

This warranty is your coverage against material and workmanship malfunction or defects in Moen products or components (Pipe kit etc.). During the warranty period, we offer free maintenance and changing of malfunctioned products or product components. Moen's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for otherwise stipulated by law.

Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty. Although the warranty period remains valid, in case of the following conditions (1) - (5), the maintenance cost (material cost and labor cost) shall still be charged as the case may be:

1. Corresponding warranty card and valid invoice cannot be presented;
2. Faults were caused by the incompliance with the instructions and precautions provided in the user's manual;
3. Damages and faults were caused by self-actuated dismantling, repair and refit;
4. Faults and damages were caused by external factors such as force majeure;
5. Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities. In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as the case may be.

For markets exclude Chinese mainland, the terms and conditions of warranty shall differ between product categories and countries. Please refer to warranty stated by local distribution.

Moen Incorporated shall have the final interpretation of Moen warranties.

©2023 Moen Incorporated
INS2329B

07/06/2023 INS2329B 3000056605
Backcard 01